

Attachment C

49 CFR 395.24 Driver responsibilities—In general.

(a) *In general.* A driver must provide the information the ELD requires as prompted by the ELD and required by the motor carrier.

(b) *Driver's duty status.* A driver must input the driver's duty status by selecting among the following categories available on the ELD:

- (1) "Off duty" or "OFF" or "1";
- (2) "Sleeper berth" or "SB" or "2", to be used only if sleeper berth is used;
- (3) "Driving" or "D" or "3"; or
- (4) "On-duty not driving" or "ON" or "4".

(c) *Miscellaneous data.* (1) A driver must manually input the following information in the ELD:

- (i) Annotations, when applicable;
- (ii) Driver's location description, when prompted by the ELD; and
- (iii) Output file comment, when directed by an authorized safety officer.

(2) A driver must manually input or verify the following information on the ELD:

- (i) Commercial motor vehicle power unit number;
- (ii) Trailer number(s), if applicable; and
- (iii) Shipping document number, if applicable.

(d) *Driver use of ELD.* On request by an authorized safety official, a driver must produce and transfer from an ELD the driver's hours-of-service records in accordance with the instruction sheet provided by the motor carrier.