

FORM C Soybean Pre-Harvest Lab Determinations 2018



WEIGHT of UNTHRESHED PODS					
1.	Weight of Unit 1 pods and beans removed from bag	rams to Hundredths	503		
2.	Weight of Unit 2 pods and beans removed from bag	rams to Hundredths	504		
COUNT of PODS from ONE UNIT (BAG) ONLY					
3.	Unit used (<i>Always use pods from Unit 1, if possible</i>)	Unit Code	512		
4.	Number of pods with developed beans	Number	513		
	(Developed beans are at least 50% of the mass of normal beans in that field. Generally, they are thicker than a nickel.)				
5.	Number of pods with undeveloped beans	Number	514		
WEIGHT and MOISTURE of THRESHED BEANS					
Thresh and hull only pods with developed beans from both units. If pods are too wet to thresh easily, pods should be dried for a short period at no more than 70 degrees C and then threshed.					
6.	Weight of all threshed beans from both units immediately before moisture test		507		
7.		rams to Hundredths ercent (One Decimal)	508		
		sushel (One Decimal)	509		
	o Technician Date Analyzed	Money (One Decimal)	· <u> </u>		
		MM	DD		

If the sample weight is too small or too dry for a moisture test, follow the procedures on the back of this form to complete the moisture test.

Bag sample for United Soybean Board

If the sample weight is too small for moisture test, sufficient grains of known moisture content (use same class and stage of maturity) will be added to the sample so that a moisture test can be made. The moisture content of the sample can then be derived using the following formula:

$$E = \frac{(A+B)D - (BxC)}{A}$$

Where	A = Weight of small or dry soybean sample	·	Grams
	B = Weight of additional beans required for moisture test	· — —	Grams
	C = Moisture percent of B	·	Percent
	D = Moisture percent of A + B combined	•	Percent
	E = Result : Moisture percent of small or dry soybean sample (<i>enter in item 7</i>)		Percent